

1945 K III

## DIP SWICH MANUAL

## DIP SWI

FUNCTION	1	2	3	4	5	6	7	8
1coin/1credit	OFF	OFF	OFF					
2coin/1credit	ON	OFF	OFF					
3coin/1credit	OFF	ON	OFF					
1coin/2credit	ON	ON	OFF					
FREE PLAY	OFF	OFF	ON					
EASY				ON	ON			
NORMAL				OFF	ON			
DIFFICULT				ON	OFF			
EXPERT				OFF	OFF			
LIFE 2						ON	OFF	
LIFE 3						OFF	OFF	
LIFE 4						OFF	ON	
LIFE 5						ON	ON	
SOUND TEST								ON

DEFAULT SETTING -ALL OFF